

MODEL

HESTIA 2 CLEAN AIR

HESTIA CLEAN AIR HW

INSTALLATION SPECIFICATION SHEET


These instructions must be used in conjunction with the 'General Installation Instructions' for MASPORT wood fires.

CLEARANCE REQUIREMENTS

present in Section 3 of AS/NZS 2918:2001.

This fire has been tested and complies to the Australian/New Zealand Standard AS/NZS 2918:2001 and all installations must be in accordance with the minimum clearances to combustibles indicated in these instructions. The minimum clearances to combustables may be reduced if the combustable walls are shielded with an approved non-combustable material. Details of suitable materials and appropriate clearance reduction factors are

POSITIONING YOUR FREE-STANDING WOODFIRE



NEW ZEALAND

MINIMUM DISTANCES TO HEAT SENSITIVE WALLS (mm)

MODEL	FLUE HEAT SHIELD		В	Е	F	G	Н	R§
HESTIA 2	MASPORT DOUBLE SKIN S/S POLISHED	50	340	25	213	660	366	518
CLEAN AIR	WITHOUT FLUE SHIELD	270	340	150	433	660	491	695

AUSTRALIA

MINIMUM DISTANCES TO HEAT SENSITIVE WALLS (mm)

MODEL	FLUE HEAT SHIELD		В	E	F	G	Н	R§
LIECTIA CLEAN	FLOWMET UNIVERSL FLUE SYSTEM	260	240	100	423	560	441	624
HESTIA CLEAN AIR HW	AIR-GROUP SPECIAL INSULATED FLUE KIT *	150	280	100	313	600	441	624
AllX HVV								

[§] Valid only when the room walls are at 90° to each other.


PRT. NO. HCAM0738
DATE: 25.07.2013

[‡] Note: Clearances are for fire hazard only. For durability of finishes or surfaces you should contact the relevant manufacturer for their specification. Glen Dimplex Australasia Ltd accepts no responsibility for the deterioration of surfaces or finishes.

^{*} Air-Group Special Insulated Flue Kit is same as AHD Special Insulated Flue Kit

FLOOR PROTECTOR (Hearth) REQUIREMENTS PARALLEL INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



DIMENSIONS IN THE TABLE ARE VALID ONLY WHEN THE FIRE IS EXACTLEY AT ITS MINIMUM ALLOWABLE WALL CLEARANCE.

NEW ZEALAND

MODEL	Flue Shield	Floor Protector height	A #	C#	D	F	I	J	K#	P2	Р3	W	Floor Protector Type Ø
HESTIA 2	MDS	ANY	50	300	130	213	600	900	820	470	163	640	AFP
CLEAN AIR	*		270	340	130	433	600	900	1040	470	163	640	AFP

MDS = Masport double skin S/S polished 1200 mm shield

AFP = ASH FLOOR PROTECTOR

AUSTRALIA - ALL WITH FLUE HEATSHIELD

MODEL	Flue Shield	Floor Protector height	A#	C#	D	F	ı	J	K#	P2	Р3	W	Floor Protector Type Ø
LIFOTIA	FUF	ANY	260	300	130	423	600	900	1030	470	163	640	AFP
HESTIA CLEAN AIR	AGA	ANY	150	300	130	313	600	900	920	470	163	640	AFP
HW													
''''													

FUF = FLOWMET UNIVERSAL FLUE SYSTEM

AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT WITH 900mm S/S REFLECTOR SHIELD

AFP = ASH FLOOR PROTECTOR

 \varnothing for minimum constructional requirements see general installation instructions.


Valid only when the fire is exactly at its minimum allowable wall clearance.

NOTE: Where a fan is being fitted, you may prefer to increase the 'A' dimension to 100 mm to provide easier access for servicing. If so, the amount you add to 'A' to bring it to 100 mm must also be added to the 'C' and 'S' dimensions.

^{*} WITHOUT FLUE SHIELD

FLOOR PROTECTORS (Hearth) REQUIREMENTS CORNER INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



DIMENSIONS IN THE TABLE ARE VALID ONLY WHEN THE FIRE IS EXACTLEY AT ITS MINIMUM ALLOWABLE WALL CLEARANCE.

NEW ZEALAND

MODEL	Flue Shield	Floor Protector Height	С	E	H#	L#	M#	N	R#	FLOOR PROTECTOR TYPE
HESTIA 2	MDS	ANY	300	25	366	1125	1008	607	518	AFP
CLEAN AIR	*	ANY	300	150	491	1302	1133	607	695	AFP

MDS = Masport double skin S/S polished 1200 mm shield

AFP = ASH FLOOR PROTECTOR

AUSTRALIA

MODEL	Flue Shield	Floor Protector Height	С	E	H#	L#	M#	N	R#	FLOOR PROTECTOR TYPE
	FUF		300	100	441	1231	1083	607	624	AFP
HESTIA CLEAN AIR	AGA		300	100	441	1231	1083	607	624	AFP
HW										
1111										


FUF = FLOWMET UNIVERSAL FLUE SYSTEM

AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT WITH 900mm S/S REFLECTOR SHIELD AFP = ASH FLOOR PROTECTOR



^{*} WITHOUT FLUE SHIELD

FREE STANDING FIRE DIMENSIONS



MODEL	P1	P3	Н	W	S1	S2	S3	S4
HESTIA 2 CLEAN AIR	523	163	753	640	-	200	120	390
HESTIA CLEAN AIR HW								

<u>Seismic Restrain</u> - In New Zealand and some part of Australia, it is required that the wood fire and floor protector are secured to prevent shifting in the event of an earthquake. This is best done by fastening the wood fire right through the protector to the floor, using two screws not less than 12 guage or the equivalent size of coach bolts or toggle fasteners.

THIS FLUE INSTALLATION DIAGRAM BELOW IS VALID FOR NZ INSTALLATIONS ONLY. FOR INSTALLATIONS IN AUSTRALIA, PLEASE REFER TO SPECIFIC FLUE INSTALLATION SPECIFICATIONS.

