
F28 MAIN ASSEMBLY



F28 BURNER & LOG ASSEMBLY

Part#: Aust. New Zealand Description


Aust. New Zealand Description

Log Set

51) 910-246	560024 ON/OFF Burner Switch (2-way)	75) 560-935
52) 910-190	597004 Piezo & Nut	
53) 910-140	560036 HI/OFF/LO Fan Switch	78) 651-580
54) 910-373	588412 Knob - Pilot Valve Extension	
55) 910-372	588413 Flame Adjusting Knoh	

56) 908-057 n/a Control Panel Decal

Burner Assy 51-580



F28 DOOR ASSEMBLIES

Part#: Aust. New Zealand Description

560-924 n/a Gold Door - Complete Assy Black Door - Complete Assy 560-926 n/a 101) 650-920 560018 Door Gasket Repair Kit 106) 940-236/P 560257 Side Glass 107) 936-243 560087 Glass Gasket 108) 940-237/P 560258 Centre Glass 112) 560-032 Door Glass Aluminium Extrusion 114) 936-264 n/a Ceramic Paper 1/16" x 3/4" 123) 560-039 Glass Retainer Side Glass Retainer Top/Bottom 124) 560-038 107 112 107 106 108 124 112 123 107 106 107 114 124 123