

MODEL

R5000WS NZ (SW) & AU (HW)

INSTALLATION SPECIFICATION SHEET


These instructions must be used in conjunction with the 'General Installation Instructions' for Masport wood fires.

CLEARANCE REQUIREMENTS

This fire has been tested and complies to the Australian/New Zealand Standard AS/NZS 2918:2001 and all installations must be in accordance with the minimum clearances to combustibles indicated in these instructions.

The minimum clearances to combustables may be reduced if the combustable walls are shielded with an approved non-combustable material. Details of suitable materials and appropriate clearance reduction factors are present in Section 3 of AS/NZS 2918:2001.

POSITIONING YOUR FREE-STANDING WOODFIRE



NEW ZEALAND

MINIMUM DISTANCES TO HEAT SENSITIVE WALLS (mm)

MODEL	FLUE SYSTEM & FLUE SHIELD	Α	В	E	F	G	Н	R§
R5000WS (SW) (Dry/Wet)	MASPORT FLUE + MASPORT 900mm DOUBLE SKIN SHIELD + TOP FLUE DIVERTER PLATE + 500x500 Ceiling Plate	170	290	135	366	640	491	695

AUSTRALIA

MINIMUM DISTANCES TO HEAT SENSITIVE WALLS (mm)

MODEL	FLUE SYSTEM & FLUE SHIELD	Α	В	E	F	G	Н	R§
DE000/4/8 (H)4/)	FLOMET UNIVERSAL FLUE SYSTEM	188	280	150	384	630	506	716
R5000WS (HW) (Dry /Fan)	AIR-GROUP SPECIAL INSULATED FLUE KIT WITH TOP DIVERTER PLATE *	125	395	155	321	745	511	723

[§] Valid only when the room walls are at 90° to each other.

‡ Note: Clearances are for fire hazard only. For durability of finishes or surfaces you should contact the relevant manufacturer for their specification. Masport accepts no responsibility for the deterioration of surfaces or finishes.


PRT. NO. 583289

DATE: 03.03.2021

^{*} Air-Group Special Insulated Flue Kit is same as AHD Special Insulated Flue Kit

FLOOR PROTECTOR (Hearth) REQUIREMENTS PARALLEL INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



DIMENSIONS IN THE TABLE ARE VALID ONLY WHEN THE FIRE IS EXACTLY AT ITS MINIMUM ALLOWABLE WALL CLEARANCE.

NEW ZEALAND

MODEL	Flue Shield	Floor Protector height	A #	C#	D	F	I	J	K#	P2	Р3	W	Floor Protector Type Ø
	RDS	ANY	170	300	100	366	600	900	1010	540	196	700	AFP
R5000WS (SW)													
(Dry / Wet)													

RDS = MASPORT DOUBLE SKIN SHIELD 900mm HIGH + TOP DIVERTER PLATE + 500x500 CEILING PLATE

AFP = ASH FLOOR PROTECTOR

AUSTRALIA - ALL WITH FLUE HEATSHIELD

MODEL	Flue Shield	Floor Protector height	A#	C#	D	F	-	J	K#	P2	Р3	w	Floor Protector Type Ø
DECCOMAC (LIMA)													
R5000WS (HW) (Dry / Fan)	FUF	ANY	188	300	100	384	600	900	1028	540	196	700	AFP
(Diy/Tall)	AGA	ANY	125	300	100	321	600	900	965	540	196	700	AFP

FUF = FLOMET UNIVERSAL FLUE SYSTEM

AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT + 900mm S/S REFLECTOR SHIELD + TOP DIVERTER PLATE

AFP = ASH FLOOR PROTECTOR


Ø for minimum constructional requirements see general installation instructions.

Valid only when the fire is exactly at its minimum allowable wall clearance.

NOTE: Where a fan is being fitted, you may prefer to increase the 'A' dimension to 100 mm to provide easier access for servicing. If so, the amount you add to 'A' to bring it to 100 mm must also be added to the 'C' and 'S' dimensions.

FLOOR PROTECTORS (Hearth) REQUIREMENTS CORNER INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



DIMENSIONS IN THE TABLE ARE VALID ONLY WHEN THE FIRE IS EXACTLY AT ITS MINIMUM ALLOWABLE WALL CLEARANCE.

NEW ZEALAND

MODEL	Flue Shield	Floor Protector Distance above Floor	С	E	Н#	L#	М#	N	R#	FLOOR PROTECTOR TYPE
	RDS	ANY	300	135	491	1339	1159	644	695	ASH
R5000WS (SW)										
(Dry / Wet)										

LDS = MASPORT DOUBLE SKIN SHIELD 900mm HIGH + TOP DIVERTER PLATE + 500x500 CEILING PLATE

AFP = ASH FLOOR PROTECTOR

AUSTRALIA


MODEL	Flue Shield	Floor Protector Distance above Floor	С	E	Н#	L#	М#	N	R#	FLOOR PROTECTOR TYPE
DE000/A/C (LIVA)										
R5000WS (HW) (Dry / Fan)	FUF	ANY	300	150	506	1360	1174	644	716	ASH
(Dry / r arr)	AGA	ANY	300	155	511	1367	1179	644	723	ASH

FUF = FLOMET UNIVERSAL FLUE SYSTEM

AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT + 900mm S/S REFLECTOR SHIELD WITH TOP DIVERTER PLATE

AFP = ASH FLOOR PROTECTOR

FREE STANDING FIRE DIMENSIONS




MODEL	P1	Р3	Н	W	S1	S2	S3	S4
R5000WS (NZ & AU)	541	196	804	700	340	170	20	662

<u>Seismic Restrain</u> - In New Zealand and some part of Australia, it is required that the wood fire and floor protector are secured to prevent shifting in the event of an earthquake. This is best done by fastening the wood fire right through the protector to the floor, using two screws not less than 12 guage or the equivalent size of coach bolts or toggle fasteners.

R5000WS Installation in Alcove/Recess situation

R5000WS burner model has been tested for alcove (recess) made of combustible material and complies as per safety standard AS/NZS 2918:2001



Note – - Refer table on Page 1 for dimension - The Ceiling height must be minimum 2400mm

THIS FLUE INSTALLATION DIAGRAM BELOW IS VALID FOR <u>NZ INSTALLATIONS</u> ONLY. FOR INSTALLATIONS IN AU PLEASE REFER TO SPECIFIC FLUE INSTALLATION SPECIFICATIONS SUPPLIED BY FLUE MANUFACTURER.

